System Info

1. On the main menu, select System Info and press [OK].

2. The System Info section will display the number of users, admin capacity, fingerprint capacity, password registration capacity, and fingerprint records used beyond the maximum limit.